

# instructions for 2000W Wallpaper Steamer

**Stock No.84434** 

Part No.EPS2000

**IMPORTANT:** PLEASE READ THESE INSTRUCTIONS CAREFULLY TO ENSURE THE SAFE AND EFFECTIVE USE OF THIS PRODUCT.





#### **GENERAL INFORMATION**

These instructions accompanying the product are the original instructions. This document is part of the product, keep it for the life of the product passing it on to any subsequent holder of the product. Read all these instructions before assembling, operating or maintaining this product.

This manual has been compiled by Draper Tools describing the purpose for which the product has been designed, and contains all the necessary information to ensure its correct and safe use. By following all the general safety instructions contained in this manual, it will ensure both product and operator safety, together with longer life of the product itself.

All photographs and drawings in this manual are supplied by Draper Tools to help illustrate the operation of the product.

Whilst every effort has been made to ensure the accuracy of information contained in this manual, the Draper Tools policy of continuous improvement determines the right to make modifications without prior warning.

#### TITLE PAGE 1.

#### 1.1 INTRODUCTION:

USER MANUAL FOR:

#### 2000W WALLPAPER STEAMER

Stock no. 84434. Part no. WPS2000

#### 1.2 REVISIONS:

Date first published November 2015			

As our user manuals are continually updated, users should make sure that they use the very latest version.

Downloads are available from: http://www.drapertools.com/manuals

DRAPER TOOLS LIMITED WEBSITE: drapertools.com

+44 (0) 23 8049 4344 **HURSLEY ROAD** PRODUCT HELPLINE:

GENERAL FAX: +44 (0) 23 8026 0784 CHANDLER'S FORD **EASTLEIGH** 

**HAMPSHIRE** SO53 1YF UK

#### 1.3 UNDERSTANDING THIS MANUALS SAFETY CONTENT:

WARNING! Information that draws attention to the risk of injury or death.

Information that draws attention to the risk of damage to the product or CAUTION!

surroundings.

#### 1.4 COPYRIGHT © NOTICE:

Copyright © Draper Tools Limited.

Permission is granted to reproduce this publication for personal & educational use only.

Commercial copying, redistribution, hiring or lending is prohibited.

No part of this publication may be stored in a retrieval system or transmitted in any other

form or means without written permission from Draper Tools Limited.

In all cases this copyright notice must remain intact.

## 2. CONTENTS 2.1 CONTENTS

	PAGE CONTENT PA	4 <i>GE</i>
1	TITLE PAGE       2         1.1 INTRODUCTION       2         1.2 REVISION HISTORY       2         1.3 UNDERSTANDING THIS MANUAL       2         1.4 COPYRIGHT NOTICE       2	
2	CONTENTS 2.1 CONTENTS	
3	GUARANTEE 3.1 GUARANTEE4	
4	INTRODUCTION       5         4.1       SCOPE       5         4.2       SPECIFICATION       5         4.3       HANDLING & STORAGE       5	
5.	HEALTH & SAFETY INFORMATION  5.1 GENERAL SAFETY INSTRUCTIONS FOR POWER TOOL USE	7
6.	TECHNICAL DESCRIPTION 6.1 IDENTIFICATION	
7.	UNPACKING & CHECKING 7.1 PACKAGING	
8.	SETTING UP THE STEAMER 8.1 ATTACHING THE STEAM PLATE & "COOL-TOUCH" HOSE12	
9.	OPERATING THE STEAMER       13         9.1 FILLING WITH HOT WATER	
10.	MAINTENANCE15	
11.	DISPOSAL 11.1 DISPOSAL 16	
12.	EXPLANATION OF SYMBOLS 12.1 EXPLANATION OF SYMBOLS 17	
DECLA	DATION OF CONFORMITY	

#### 3. GUARANTEE

#### 3.1 GUARANTEE

Draper tools have been carefully tested and inspected before shipment and are guaranteed to be free from defective materials and workmanship.

Should the tool develop a fault, please return the complete tool to your nearest distributor or contact Draper Tools Limited, Chandler's Ford, Eastleigh, Hampshire, SO53 1YF. England. Telephone Sales Desk: (023) 8049 4333 or Product Helpline (023) 8049 4344.

A proof of purchase must be provided with the tool.

If upon inspection it is found that the fault occurring is due to defective materials or workmanship, repairs will be carried out free of charge. This guarantee period covering parts/labour is 12 months from the date of purchase except where tools are hired out when the guarantee period is 90 days from the date of purchase. The guarantee is extended to 24 months for parts only. This guarantee does not apply to normal wear and tear, nor does it cover any damage caused by misuse, careless or unsafe handling, alterations, accidents, or repairs attempted or made by any personnel other than the authorised Draper warranty repair agent.

Note: If the tool is found not to be within the terms of warranty, repairs and carriage charges will be quoted and made accordingly.

This guarantee applies in lieu of any other guarantee expressed or implied and variations of its terms are not authorised.

Your Draper guarantee is not effective unless you can produce upon request a dated receipt or invoice to verify your proof of purchase within the guarantee period.

Please note that this guarantee is an additional benefit and does not affect your statutory rights.

Draper Tools Limited.

#### 4. INTRODUCTION

#### 4.1 SCOPE

The wallpaper steamer described in the manual is designed for fast and efficient removal of most types of wallpaper and other decorative surfaces. Any other application is considered misuse.

#### **4.2 SPECIFICATION**

Stock no	84434
Part no	WPS2000
Rated voltage	230V~50Hz
Rated input	2000W
Water tank capacity	4.5 litres
Heat up time	10mins (approx.)
Single fill duration	60mins (approx.)
Safety cutout feature	@ 105°C
Protection rating	IPX4
Weight (empty tank & 2 steam plates	

#### DANGER OF INJURY - HOT WATER/STEAM WILL BURN

#### 4.3 HANDLING & STORAGE

Without regular cleaning, debris can clog the machine resulting in poor performance.

#### 5. HEALTH & SAFETY INFORMATION

Have this tool repaired by a qualified person. This tool is designed to confirm to the relevant international and local standards and as such should be maintained and repaired by someone qualified; using only original parts supplied by the manufacturer: This will ensure the tool remains safe to use.

#### 5.1 GENERAL SAFETY INSTRUCTIONS FOR POWER TOOL USE

**Warning:** Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

Save all warnings and instructions for future reference.

The term "power tool" in the warnings refers to your mains operated (corded) power tool or battery-operated (cordless) power tool.

- 1 Work area safety
  - a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
  - b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
  - c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

#### 2 Electrical safety

- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- b) Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts.

  Damaged or entangled cords increase the risk of electric shock.
- e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
- f) If operating a power tool in a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

#### 3) Personal safety

- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
- b) Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
- c) Prevent unintentional starting. Ensure the switch is in the off position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your finger on the switch or energising power tools that have the switch on invites accidents.

#### 5. HEALTH & SAFETY INFORMATION

- d) Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.
- e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
- f) Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewellery or long hair can be caught in moving parts.
- g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust-related hazards.

#### 4) Power tool use and care

- a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.
- b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.
- c) Disconnect the plug from the power source and/or battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.
- e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
- f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
- g) Use the power tool, accessories and tool bits etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from those intended could result in a hazardous situation.

#### 5) Service

a) Have your power tool serviced by a qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

#### **IMPORTANT**

On products exceeding 2000W it is recommended that the power cable and/or extension cable are fully unwound before a connection is made to the power supply. However, ensure the residual cable does not pose a trip hazard.

#### HEALTH & SAFETY INFORMATION

#### 5.2 SPECIFIC SAFETY INSTRUCTIONS FOR WALLPAPER STEAMER USE

- · Keep equipment away from children and pets.
- Ensure boiler is placed on a flat level surface, and should the boiler become tilted in use level again immediately.
  - Failure to do so can result in severe overheating, complete element failure and void of your guarantee.
- Block boiler unit securely if using on stairs.
- The boiler becomes hot in use. Move only by using the carrying handle.
- Steam is produced at 100°C. Be careful, wear protective clothing and protect your hands with heat resistant gloves or mitts.
- Never point hose or steam plate at anyone.
- Always keep steam plate tilted away from face and body, beware of hot drips and regularly empty collected condensation from plate - especially when stripping ceilings and high areas.
- Never remove filler cap or detach hose whilst unit is operating.
- Never block the safety valve.
- Switch off and wait for 2 minutes before removing filler cap to refill boiler.
- Do not overfill.
- Allow to cool completely before emptying boiler.
- Do not stand on boiler or hose.
- Do not drag or try to move boiler by pulling the mains lead.
- Do not allow water or steam to enter light switches or power points.
- Do not leave unattended.
- Use only standard tap water. Never add detergents or chemicals.
- Extreme care must be taken if the unit is used in bathrooms. Always be aware of danger of
  electrocution from stored water in baths and sinks.
- Never change tools when the unit is operating.
- Always store upright.
- Do not overfill the reservoir.
- It is recommended that a RCD (residual current device) rated at 30mA is fitted into the mains supply socket for added protection against electric shock.
- Check the state of your plaster before starting work.
  - WARNING: Steam can loosen weak, porous or poorly bonded plaster- which also loosens readily if cracked, holed or if the steam plate is held in one position for too long after the paper is soaked.
- Weak plaster can normally be detected by tapping a few. areas of wall. A hollow sound indicates that you should proceed only with extreme care stopping immediately if you hear a cracking sound or plaster starts to break loose.
- The steam stripper is safe for drywall/plaster board surfaces but whatever the material, it is always wise to check a small area before starting work properly.

#### 5. HEALTH & SAFETY INFORMATION

#### 5.3 CONNECTION TO THE POWER SUPPLY

Make sure the power supply information on the machine's rating plate are compatible with the power supply you intend to connect it to.

If a replacement plug is to be fitted this must be carried out by a qualified electrician.

The damaged or incomplete plug, when cut from the cable shall be disabled to prevent connection to a live electrical outlet.

This appliance is Class I<sup>†</sup> and is designed for connection to a power supply matching that detailed on the rating label and compatible with the plug fitted.

If an extension lead is required, use an approved and compatible lead rated for this appliance. Follow all the instruction supplied with the extension lead.

 $^{\dagger}$ Earthed  $\stackrel{\bot}{=}$ : This product requires an earth connection to protect against electric shock from accessible conductive parts in the event of a failure of the basic insulation.

### 6. TECHNICAL DESCRIPTION

#### **6.1 IDENTIFICATION**



- Hose connection/outlet.
- ② Cap.
- 3 Carrying handle.
- 4 Power socket.
- (4.5 litre capacity).

#### 7. UNPACKING & CHECKING

#### 7.1 PACKAGING

Carefully remove the machine from the packaging and examine it for any sign of damage that may have happened during shipping. Lay the contents out and check them against the parts shown below. If any part is damaged or missing; please contact the Draper Helpline (the telephone number appears on the Title page) and do not attempt to use the machine.


The packaging material should be retained at least during the guarantee period: in case the machine needs to be returned for repair.

Warning! Some of the packaging materials used may be harmful to children. Do not leave any of these materials in the reach of children.

If any of the packaging is to be thrown away, make sure they are disposed of correctly; according to local regulations.

#### 7.2 WHAT'S IN THE BOX?

As well as the steamer; there are several parts not fitted or attached to it.



- 6 Large steam plate.
- 7 "Cool-touch" hose.
- 8 Small steam plate.
- 9 Power cable (not shown).

#### 8. SETTING UP THE STEAMER


NOTE: Remove the plug from the socket before carrying out adjustment, servicing or maintenance.

## 8.1 ATTACHING THE STEAM PLATE & "COOL-TOUCH" HOSE - FIGS. 1 - 3


Attach "cool-touch" hose 7 to main steamer unit item 1 at one end. At the remote end attach "cool-touch" hose 7 to small steam plate 9.

Note: If you want to use the large steam plate (6) then the small steam plate (9) has to be located within it (see Fig.3).

NB: Reverse this action to use the small steam plate only (6).







#### 9. OPERATING THE STEAMER

NOTE: Do not leave unattended and keep children and pets out of the room.


## 9.1 FILLING WITH HOT WATER - FIGS. 4 - 5


Remove the reservoir cap ② and pour in the tap water (preferably hot, max 4.5 litres), avoiding spillage. Do not overfill the unit or hot water will be forced up the steam hose. Observe the level indicator ⑤:1) on the side of the reservoir when filling. Ensure the cap is replaced and secured tightly but do not over tighten. Never use this unit with the cap missing or loose. Do not fill past the maximum mark.

NOTE: Ensure the unit and your hands are fully dry prior to plugging in.

WARNING: Beware of hot water discharge prior to steam emission.

WARNING: Only operate this machine by placing it on a stable flat surface.






## 9.2 ATTACHING THE POWER LEAD - FIG. 6

Plug the adaptor end of the power lead into socket 4. It is advisable to use a residual current device (RCD - Draper Stock No.69307) in conjunction with this unit.

NOTE: This unit will automatically begin the boiling process when power is switched on at the mains socket



#### 9.3 PREPARATION

To achieve fastest paper removal always gently score the areas to be stripped.

With heavily embossed, vinyl coated or painted papers this is essential. Either use a proprietary perforator tool or alternatively score the paper with the edge of a wall scraper in a criss-cross pattern with 150mm (6 inch) spacing.

As with all decorating work be sure to protect carpets and furniture with covers. Please check

drapertools.com for all these decorating accessories.

NOTE: You should only proceed at your own risk

#### 9.4 STRIPPING - FIG. 7

While the unit is heating the water to boiling point, (approx.10mins) do not leave the steam plate resting down or unattended. When boiling point is reached, take care as boiling water droplets can be expelled from the steam plate/hose area. This coughing and spluttering is normal, but be careful the water/steam is hot.

When constant steam is being produced, place the steam plate flat against the work surface. It is advisable to carry out a test on the surface to be worked on. Hold the steam plate against the area for no more than 10secs. Assess the porosity of the surface. Based on these results continue accordingly.

NOTE: Always wear suitable heat resistant gloves and a long sleeved top. Beware of hot water accumulating in the steam plate as this could cause scolding if spilt.

RISK OF ELECTRIC SHOCK! Do not allow steam or water droplets near or into electrical outlets or fittings.

#### 9.5 REFILLING AND EMPTYING - FIG. 8

Switch off and unplug the unit when the water level is low or when the automatic cut-off functions. Do not use the unit with the water level below min.

Allow the water to cool down for 5mins before removing the cap. Wear gloves to do this. Refill the unit according to instructions on page 13.

To empty the machine, allow the water to cool fully before attempting. Tip the water back out through the inlet.

Should the machine cut out at any stage during operation, switch off and unplug the power lead from the socket.

Allow the machine to rest/cool for approximately 10-15mins and the thermal cut-out will reset.

NOTE: The cut-out will not protect against the heating element being exposed out of the water for longer than 5 seconds. Any longer exposure will cause damage to the unit.





#### 10. MAINTENANCE

Regular inspection and cleaning reduces the necessity for maintenance operations and will keep your tool in good working condition.

#### 11. DISPOSAL

#### 11.1 DISPOSAL

- At the end of the machine's working life, or when it can no longer be repaired, ensure that it is disposed of according to national regulations.
- Contact your local authority for details of collection schemes in your area. In all circumstances:
  - Do not dispose of power tools with domestic waste.
  - Do not incinerate.
  - Do not abandon in the environment.
  - Do not dispose of WEEE\* as unsorted municipal waste.



\* Waste Electrical & Electronic Equipment.

#### 12. EXPLANATION OF SYMBOLS

#### 12.1 EXPLANATION OF SYMBOLS



WEEE Do not dispose of Waste Electrical & Electronic Equipment in with domestic rubbish



Warning! Wear suitable respiratory protection.



Warning! Wear suitable welding eye/face protection.



Warning! Do wear gloves.



Warning! Read the instruction manual





#### **CONTACTS**

DRAPER TOOLS LIMITED,

Hursley Road, Chandler's Ford, Eastleigh, Hampshire. SO53 1YF. U.K.

Helpline: (023) 8049 4344

- **Sales Desk:** (023) 8049 4333

- **General Enquiries:** (023) 8026 6355

Service/Warranty Repair Agent

For aftersales servicing or warranty repairs, please contact the Draper Tools Helpline for details of an agent in your local area.

YOUR DRAPER STOCKIST

RDKC1115





